



# **Baby Lock Solaris (Model BLSA) Software Update Version 1.20**

August 2018


## **Introduction**


If the software version of your Solaris (Model BLSA) is earlier than version 1.20, an update program is now available for download to improve its performance.

## **Version 1.20 update will provide the following changes:**

1. Stitch or embroidery data can be recalled from USB CD / DVD drive connected to the machine.
2. The USB embroidery card reader will be available.
3. Functionality of viewing operation manual on the machine is improved.
4. Improved reaction of LCD screen.
5. The function to play the tutorial videos on the machine screen will be available.  
In order to use this function, it is necessary to install the tutorial videos data on the machine in addition to the software update.  
After updating your machine's software to version 1.20, install the tutorial videos data.
6. Revised the built-in operation manual.

## **How to confirm the software version of your BLSA**


1. Press the power switch to "I" to turn on your machine.
2. If the opening movie is played, touch anywhere on the LCD screen.
3. Press  (Machine setting screen key) to display the machine's settings screen.



4. The machine's settings screen appears.
5. Switch the settings screens by using  (Previous page key) or  (Next page key) to display the machine's program version.



6. Check the version shown on the display.



- If “**Version**” shown in the screen is already “**1.20**” or later, it is not necessary to update your machine with the software on this page.

## How to download the update program

1. Create a temporary folder (ex. C:\Temp) on your computer to save the program file to be downloaded.
2. Click the Download link on the download page for your machine.
3. Select the previously created temporary folder (ex. C:\Temp) where the downloaded file should be stored, and then download the file.

Download file: XP\_V120A\_taco\_P.upf, size: 129 MB)


## How to update your machine’s software



You can use a USB Flash drive to update your machine's software.


### \*\*\* NOTE \*\*\*


- Do not turn off your machine while the machine is saving the update software to itself. If the machine's power is turned off while saving the update software, it may result in damage to the machine.
- Use a 4GB or larger USB flash drive when updating the machine.
- Check that no data except for the update file is saved on the reformatted USB Flash drive, before beginning update.


1. Insert the USB Flash drive into the USB port on the computer.
2. Copy the update file to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.
4. While pressing the "Automatic Threading" button, turn the main power to ON.




5. The upgrade screen will appear on the LCD. Press  or  .



 : Press this key to load the program file from the USB flash drive plugged into the USB port for media

 : Press this key to load the program file from the USB flash drive plugged into the USB port for mouse

6. Insert the USB flash drive into the USB port on the machine corresponding to the USB key pressed in step 5.



① USB port for media      ② USB port for mouse      ③ USB flash drive



7. Press Load key.



8. When the message "Upgrade complete" appears, the update file has been loaded.



9. Remove USB Flash drive from the USB port on the machine.
10. Turn the machine off and on again.
11. Your machine's software has been updated to version 1.20.

In order to play the tutorial videos on the machine, it is necessary to install the tutorial videos data on the machine in addition to the software update.

Go to Download page to install the tutorial videos data into your machine.