



Baby Lock Flourish II (Model BLMFO2) Software Update Version 1.26

April 2020


Introduction

If the software version of your Flourish II (Model BLMFO2) is earlier than version 1.26, an update program is now available for download to improve its performance.

Version 1.26 update will provide the following changes:

1. Periodic software update only, does not affect consumer features.

To confirm the software version of your BLMFO2

2. Press the power switch to "|" to turn on your machine.
3. Press  (Settings key) to display the machine's settings screen.
4. Switch the settings screens by using ◀ (Previous page key) or ▶ (Next page key) to display the machine's program version.



5. If the "Version" shown in the screen is already "1.26" or later, it is not necessary to update your machine with this software version.


How to update your machine's software


You can use a USB Flash drive to update your machine's software.

*** NOTE ***


- Do not turn off your machine while the machine is saving the update software to itself. If the machine's power is turned off while saving the update software, it may result in damage to the machine.
- Use a 4GB to 8 GB USB flash drive when updating the machine.
- Check that no data is saved on the **formatted** USB Flash drive, before beginning update.

1. Insert the USB Flash drive into the USB port on the computer.
2. Copy only the update file, FEMTE1A126.upf, to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.

1. Turn on your machine while pressing and holding  (Presser foot lifter button).




2. The following screen will appear on the LCD.







3. Insert the USB flash drive into the USB port on the machine.



4. Touch  (LOAD key).



5. The following screen appears on the LCD. Do not turn off your machine while the machine is saving the update software to itself.



6. When the following screen appears, updating is completed.



7. Remove the USB flash drive and turn the machine off and on again.
8. The machine's software has been updated to version 1.26.