



# **Baby Lock Verve (Model BLMVR) Software update version 1.08**

February, 2022


## **Introduction**

If the software version of your Verve (Model BLMVR) is earlier than version 1.08, an update program is now available for download to improve its performance.

## **Version 1.08 update will provide the following change:**


1. Improved machine's functionality for displaying the maintenance message.
2. Improved the thread color display on the screen when using a pattern data that contains the embroidery thread brands or thread number that are not defined in the embroidery machine.


## **How to confirm the software version of your BLMVR**

1. Turn on the machine. The LCD comes on. If the opening movie is played, press anywhere on the screen.
2. Touch  (Settings Key) on the operation panel.



The settings screen appears.

3. Switch screens by using  (Previous page key) to display the software version.



4. If the version shown in the screen is already "1.08" or later, it is not necessary to update your machine with this software version,




## How to update your machine's software


You can use a USB Flash drive to update your machine's software.

### \*\*\* NOTE \*\*\*


- Do not turn off your machine while the machine is saving the update software to itself. If the machine's power is turned off while saving the update software, it may result in damage to the machine.
- Use a 4GB to 8 GB USB flash drive when updating the machine.
- Check that no data is saved on the **formatted** USB Flash drive, before beginning update.

1. Insert the USB Flash drive into the USB port on the computer.
2. Copy only the update file, MCBTE1A108.upf, to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.


4. Turn on your machine while pressing and holding  (Needle position button).




5. The following screen will appear on the LCD.



6. Insert the USB flash drive into the USB port on the machine.




7. Touch  (LOAD key).





8. The following screen appears on the LCD. Do not turn off your machine while the machine is saving the update software to itself.



9. When the following screen appears, updating is completed.



10. Remove the USB flash drive and turn the machine off and on again.
11. The machine's software has been updated to version 1.08.

## Baby Lock Verve (Model BLMVR) Update History

### ➤ **Version 1.07 update will provide the following change:**

1. Periodic software update, does not affect consumer features.

### ➤ **Version 1.06 update provided the following change:**

1. The foot control communication with the machine has been optimized.

### ➤ **Version 1.03 update provided the following changes:**

1. Improved machine's functionality for the following features.
  - Memory function
  - Pattern selecting and editing function